


## **480R Installation Guide**











5







Outside leg bolts mount from top - 2 Carriage bolts per leg




Inside leg bolts mount from beneath - 2 Hex bolts per leg





### **Install Vertical Section**

\*Remove 2 small socket screws on back panel to access vertical cavity





\*Vertical aligning screws already intalled & set at factory - Do Not Adjust





Top

Snap connector into terminal hole at lower end of vertical channel and the second cable connects to LED display circuit board at top.

Pass the 2 cables through hole at bottom of vertical housing

\*Gently tap lower area of vertical case to help align vertical holes




# 7

#### Replace back panel & Install Hole caps



Slide backing panel back into position and secure with supplied screws





A) Remove yellow bar

(1 screw at each end)

- B) Remove the 2 front panel covers to allow access for installing the two remaining rollers.

  You will find 1 screw in the middle of each panel on the roller side.


  Each panel is held in position by non-screwing set screws.
- C) Insert roller with spring loaded rod end at front hole first then push the rod at the opposite back end while sliding it down until it slips into the hole on the back panel.

  Install the second roller the same.


### Secure cables with clamps




Cable clamps can be installed under platform to enable cables to be neatly secured



Screw holes for securing cable clamps



Height of leading roller (both ends) can be adjusted higher than platform rollers to prevent boxes on the line from riding onto platform aggresively



Roller adjustment made at bottom of each corner channel